



# A412MWS

Windscreen

Shure online user guide for Microflex metal windscreen model A412MWS.  
Version: 4.0 (2020-H)

# Table of Contents

A412MWS Windscreen	3	MODEL A412MWS	3
--------------------	---	---------------	---

---

# A412MWS Windscreen

---

## MODEL A412MWS

1. Loosen the setscrew on the windscreen collar with the supplied miniature hex wrench.
2. Slide the windscreen over the microphone head until it stops.
3. Tighten the setscrew to secure the windscreen.

- The windscreen collar must not block the sound ports on the microphone.
- The setscrew should rest in the groove around the microphone base.



