

# THIS SYSTEM IS EQUIPPED WITH A SHURE STEREO DYNETIC® PHONOGRAPH CARTRIDGE

## MODEL M74CS with SPHERICAL STYLUS

Stylus: N74C, Spherical (Conical) Tracking Force: 2 to 4 grams

Grip Color: Blue with Silver Letters
Frequency Response: 20 to 20,000 Hz
Channel Separation: 20 dB minimum

at 1 kHz

Channel Balance: Within 2 dB

Trackability (in cm/sec peak velocity, at 3 grams):

400 Hz—26 cm/sec 1,000 Hz—37 cm/sec 10,000 Hz—14 cm/sec

Optional 78 rpm Stylus: Model N75-3

#### STYLUS REPLACEMENT



Grasp molded housing of stylus and gently pull forward out of cartridge. Insert replacement stylus into socket and press until housing mates with cartridge case.

### RECOMMENDED STYLUS CLEANING

Use a camel's hair brush (No. 2 size or smaller) trimmed to approximately 6 mm (1/4 in.) dipped in alcohol or an alcohol-distilled water solution. Commercial cleaning solutions may cause stylus damage or corrosion. Always brush stylus from back to front; never brush or wipe stylus from front to back or side to side.

### SPECIAL NOTE

To maintain the original performance standards of your cartridge, be certain to buy only a genuine Shure replacement stylus. AVOID IMITATIONS. THEY WILL SERIOUSLY DEGRADE THE PERFORMANCE OF YOUR CARTRIDGE. ALL GENUINE "DYNETIC®" STYLI ARE MANUFACTURED BY SHURE BROTHERS INC. LOOK FOR THE NAME SHURE ON THE STYLUS GRIP. For more information on your Shure stylus, write for booklet: "A Visit to the Small World of a Stylus."

## **FULL ONE-YEAR WARRANTY**

Shure Brothers Incorporated ("Shure"), 222 Hartrey Avenue, Evanston, Illinois 60204, warrants to the owner of this product that it will be free, in normal use, of any defects in workmanship and materials for a period of one year from date of purchase. You should retain proof of date of purchase. Shure is not liable for any consequential damages. If this Shure product has any defects as described above, carefully repack the unit and return it prepaid to:

Shure Brothers Incorporated Attention: Service Department 1501 West Shure Drive Arlington Heights, Illinois 60004

If you are not in the United States, return the unit to your dealer or Authorized Service Center for repair. The unit will be repaired or replaced and returned to you promptly and, if it cannot be repaired or replaced, you may elect to receive a refund. This warranty does not include stylus wear.

Copyright 1979, Shure Brothers Inc. 27A1526 (SF) DC74CS

28-249-04

Printed in U.S.A.