





Removing the Microphone Handle



- 1. Unscrew and remove the battery cover.
- Unscrew the grille and carefully remove it so that it does not scrape against the microphone assembly underneath.
- 3. Remove the lock ring using the same procedure as removing the grille.
- 4. Slide the cover off the microphone.

Installing the Custom Handle



- 1. Slide the new cover onto the top end of the microphone.
- 2. Carefully slide the lock ring over the microphone assembly and tighten clockwise.
- Gently guide the grille over the microphone assembly and tighten clockwise
- 4. Install the new battery cover on the microphone and rotate clockwise to tighten.

©2017 Shure Incorporated 1/1