MICROPHONES AND ELECTRONIC COMPONENTS

AREA CODE 312/328-9000 . CABLE: SHUREMICRO

MODEL M71C **EASY-MOUNT**

DATA SHEET STEREO DYNETIC® PHONOGRAPH CARTRIDGE

SPECIFICATIONS

M71 AND M73 CARTRIDGE SERIES N71 AND N73 STYLI SERIES

Model Number	Diamond Stylus Replacement	Output Voltage (1,000 Hz. at 5 cm/sec.)	Stylus Color Grip	Tracking (Grams)
M71EB	NEB71 Elliptical Side Contact Radius: .0004" (.010 mm) Frontal Radius: .0007" (.018 mm)	6.2 millivolts	Green	1½ to 3
M71-6	NB71-6 Radius: .0006" (.015 mm)	6.2 millivolts	Beige	1½ to 3
M71C	NC71 Radius: .0006" (.015 mm)	9.0 millivolts	Blue	3 to 5
M73G	N73G Radius: .0006" (.015 mm)	6.2 millivolts	Gray	1 to 1½
	N75-3,* Radius: .0025" (.064 mm)	4.4 millivolts (monaural)	Green	1½ to 3

*The N75-3 stylus may be used to reproduce the standrpm records. In this case, the amplifier should be set to aural" or "A+B." standard 78

TRACKABILITY:

M71EB at a stylus force of 1½ grams 400 Hz. — 14.3 cm/sec.

M71-6 at a stylus force of 1½ grams 400 Hz. — 14.3 cm/sec. M71C at a stylus force of 3 grams 400 Hz. — 14.3 cm/sec.

M73G at a stylus force of 1 gram 400 Hz. — 14.3 cm/sec.

Higher stylus forces within specified range improve trackability.

FREQUENCY RESPONSE: From 20 to 20,000 Hz.

CHANNEL SEPARATION: More than 20 db at 1,000 Hz.

RECOMMENDED LOAD IMPEDANCE: 47,000 ohms per channel

INDUCTANCE: 720 millihenries D.C. RESISTANCE: 630 ohms.

MOUNTING: Standard ½" (12.7 mm) mounting center using new "Easy-Mount" snap-in bracket.


WEIGHT: 5 grams

TERMINALS: 4 terminals

GENERAL: The M71 and M73 Series of Dynetic phonograph cartridges has been developed for use with all high fidelity amplifiers having magnetic and constant velocity inputs.

MOUNTING: The cartridge bracket has standard ½" mounting centers. Hardware is provided for mounting purposes. (The brass screws have British threads.)

- Remove stylus guard and stylus from cartridge. (See paragraph on stylus replacement.)
 Remove cartridge from "Easy-Mount" snap-in bracket. (See (Figure 1) 1.
- 2
- 3
- Start mounting screws into tone arm head or plug-in shell. Slip "Easy-Mount" bracket under heads of mounting screws and tighten screws securely. 4.
- Connect leads to phono-cartridge. Note color code for proper connection to terminal "L," "R," "LG" and "RG" as indicated in tone-arm instruction manual.
- Insert cartridge into Figure 1) "Easy-Mount" snap-in bracket. (See 6.



CARTRIDGE AND BRACKET ASSEMBLY FIGURE 1

- The top of the "Easy-Mount" bracket should be fluch against the top of the tone arm head for proper playing position, unless other mounting instructions are supplied by the record changer/tone arm manufacturer.
- Reinsert stylus.

SHURE-SME MOUNTING INSTRUCTIONS: To mount the cartridge in the Shure-SME Precision Pickup Arm, Model 3009 and 3012, refer to the paragraphs on Cartridge Installation and Balancing in the instruction Manual supplied with the pickup arms.

OPERATION: Recommended needle forces for optimum are listed under "Specifications." Forces greater than t cated "maximum" should not be used. the

CONNECTIONS

4-LEAD STEREO CONNECTION: Connect "hot" lead of right channel to terminal "R" and shield or ground lead of right channel to terminal "RG." Connect "hot" lead of left channel to terminal "L" and shield or ground lead of left channel to "LG." To prevent "ground loops" and hum, no common connection should be used at cartridge terminals.

MONAURAL CONNECTION: For single channel reproduction of Monaural or Stereo recordings, connect "hot" lead to both "R" and "L" terminals and connect ground or shield lead to both ground terminals marked "RG" and "LG."

Suggestions for Cleaning Your Stylus

To clean the stylus, use a camel's-hair brush (No. 2 size or smaller) dipped lightly in alcohol. The alcohol will remove any studge deposits which may have coated the stylus tip. The brush bristles should be trimmed to a length no longer than ¼ inch. Always brush the stylus with a torward movement from the rear (terminal end of the cartridge) to the front. Never brush or wipe the stylus from front to back or side to side.

CAUTION: Do not make solder connections to cartridge termi-nals. Make all solder connections to terminal jacks provided before slipping them over the terminals. - RIGHT J. LEFT --GROUND RO LEFT CHANNE GROUND) L.G CHANNEL GROUND (GROUNDED TO CASE) RG(O

TERMINAL DIAGRAM FIGURE 2

STYLUS REPLACEMENT FIGURE 3

EASY STYLUS REPLACEMENT

Grasp molded housing of stylus between thumb and forefinger. Gently withdraw stylus by pulling forward out of cartridge. Grasp replacement stylus between thumb and forefinger and insert into stylus socket. Press stylus into socket until the molded housing of the stylus mates with the cartridge case. Care must be taken not to allow the finger to slip off the molded housing of the stylus, resulting in damage to the stylus tip or shank.

SPECIAL NOTE: The Dynetic stylus assembly used in these cartridges is the most critical component. To maintain the original performance standards of your cartridge, be certain that any replacement stylus your buy bears the following certification on the package: "This Stereo Dynetic stylus is precision manufactured by Shure Brothers, Inc."

AVOID INFERIOR IMITATIONS. THEY WILL SERIOUSLY DEGRADE THE PERFORMANCE OF YOUR CARTRIDGE, ALL GENUINE "DYNETIC" STYLI ARE MANUFACTURED BY SHURE BROTHERS INC.

LABORATORY TEST FINDINGS: (Note: The following stylus test findings of the Shure N3D stylus are an example of the close scrutiny Shure pays to all imitation Shure Dynetic Styli.) Shure laboratory tests show that the imitation stylus assemblies labeled as replacements for the Shure Model N3D Stylus Assembly vary drastically in important performance characteristics. For example, the compliance varied from a low of 0.9 to a high of 11.5, requiring 9.0 grams to track a record with a low compliance stylus, and 2 grams with a high compliance stylus. The high compliance stylus retracted at 4 grams needle force, allowing the cartridge case to drag on the record surface, thereby becoming inoperative. Response at high frequency (relative to the Ikc level) ranged from 4.5.5db peak to a drop of 7.5db. Separation varied from "good" (27db) to "poor" (16.5db), at 1 kc. These figures reveal that there is very little consistency in performance characteristics of the imitation Dynetic Styli.

Innuation Dynetic Styll.

In each of the categories shown above the results ranged from good to poor. As a matter of fact, only 10% of the samples met the Shure performance standards for the Shure N3D Stereo Dynetic Stylus. In addition to our test findings, our Service Department records show that an increasing number of Dynetic Phono Cartridges are being returned because of poor performance—and our examination has disclosed that most of these returned cartridges are using imitation Dynetic Styli.

CONCLUSION: Obviously, if any imitation Dynetic Stylus is used, we cannot guarantee that the performance of Shure Dynetic cartridges will meet the published Shure specifications. Accept no substitute.

GUARANTEE: This Shure product is guaranteed in normal use to be free from electrical and mechanical defects for a period of one year from the date of purchase. Please retain proof of purchase date. This guarantee includes all parts and labor. This guarantee does not include stylus wear.

SHIPPING INSTRUCTIONS: Carefully repack the unit and return it prepaid to the factory. If outside the United States, return the unit to your dealer or authorized Shure Service Center for repair. The unit will be returned to you prepaid.

PATENT NOTICE: Cartridge and stylus manufactured under one or more of the following U.S. Patents 3,055,988, 3,077,521, 3,077,522, and 3,463,889.